

# **Dryden WoodMaster**

# **Coatings Specification**

This specification sheet relates to the selected Dryden WoodMaster for the purpose of protecting wood surfaces for the below project.

Project:

Contract:

Building:

Location:

Agent:

Specification no:

Prepared by: Dryden Distribution Ltd

Date:

#### Scope

The work involved and intended in this Contract is to be carried out at the location detailed above. It comprises the preparation of all surfaces and the application of Dryden WoodMaster in accordance with this specification and the manufacturer's instructions.

#### **Tenders and Contract Form**

The successful Contractor may be required to sign a contract in relation to this specification to indicate that they have made themselves entirely familiar with their obligations as set out in this specification. This is the specification referred to in our Contract

Dated:			
Owner:			
Witness:			
Contractor:			
Witness:			

#### **Site Examination**

Contractors are advised to examine the site before tendering. The submitting of a tender will be taken as an indication that the Contractors have visited the site and made themselves familiar with any matters that might affect the fulfilment of their part of the Contract and have made due allowance in their tender for these. No consideration shall be granted for any misunderstanding as to the work to be performed or materials to be used.

#### **Time to Completion**

The Contractors shall state in their tender:

- a) The date on which they could commence performance of the Contract.
- b) The period they will require in which to complete the Contract.
- c) The minimum number of workers they intend to have working on the performance of the Contract.

#### Access

Access to the site of works for the purpose of carrying out the works shall be given to the Contractor on the date for commencement of the Contract. The Contractor shall begin the works immediately after such access has been given and shall proceed regularly with the same and shall complete performance of the Contract within the time specified.

#### **Bylaws and Regulations**

The whole of the painting operations shall be carried out in conformity with Regulations and Requirements of all Public Bodies having jurisdiction in the matter and the Contractor shall pay any fees which may be payable in respect thereof.

#### General

This specification has been written in good faith with correct information available at the time. It is assumed that the nominated Contractor/applicator has the necessary experience and equipment to complete the requirements of this specification. If any substrate differs or is missing from this specification, please advise the writer.

Any other questions arising from the specification should be referred to the writer or Dryden WoodMaster, at the address below.

## Contents

- 1. Documents
- 2. Requirements of the Contractor
- 3. Products and Materials
- 4. Execution
- 5. Application Preparatory Work
- 6. Application Timber
- 7. Completion and Clean Up
- 8. Maintenance
- 9. Selections

# **1.0 DOCUMENTS**

### **1.1 Referred Documents**

Documents referred to in this section are:

- Health and Safety in Employment Act 1992
- AS/NZS 2311 Guide to the painting of buildings
- OSH Guidelines for the provision of facilities and general safety in the construction industry
- MPNZA Painters' Hazard handbook

The documents listed above and the cited clauses that follow are part of this specification. However, this specification takes precedence in the event of there being a variance with the cited document.

### **1.2 Manufacturer's Documents**

Manufacturer's and supplier's documents relating to work in this section are: Dryden WoodMaster, Specification sheet and Tech Data pages. Copies of the above documents are available from: Web: www.dryden.co.nz Email: info@dryden.co.nz Telephone: +64 9 448 1335 Facsimile: +64 9 448 1339 Freephone: 0800 379 336

### **1.3 Abbreviations**

The following abbreviations are used throughout this part of the specification: MPNZA – Master Painters New Zealand Association.

### **1.4 No Substitutions**

Substitutions are not permitted to any specified Dryden brand products, components or accessories.

## 2.0 REQUIREMENTS OF THE CONTRACTOR

### **2.1 Qualifications**

Painters to be experienced competent workers, familiar with the materials and the techniques specified.

#### **2.2 Control Samples**

Prepare samples of the finished work as scheduled, including preparation and colour as specified. Obtain approval of the appearance before proceeding. Refer to SELECTIONS.

### 2.3 Health and Safety

Refer to the requirements of the Health and Safety in Employment Act and OSH "Guidelines for the provision of facilities and general safety in the construction industry". If the elimination or isolation of potential hazards is not possible then minimise hazards on site by using the proper equipment and techniques as required in the MPNZA Painters' Hazard handbook. Supply protective clothing and equipment. Inform the Contractor as well as the employees and others on site of those hazards and put in place procedures for dealing with emergencies.

Dryden WoodMaster Page 3 of 9

### 2.4 Data Sheets

Obtain Dryden Data Sheet for each product used and keep data sheets on site. Ensure all applicators have read the material Data Sheet for each product prior to use and comply with the required safety procedures.

#### 2.5 Warranty

Please read all notes on this document including section 2.8. Refer Consumer Guarantees Act.

#### 2.6 Guarantee

The Contractor guarantees this work under normal conditions of use against failure of materials as according to the Dryden WoodMaster Specifications and Product Data Sheets.

Refer to the general section for the required form of guarantee and details of when completed guarantees must be submitted. The Contractor is to guarantee their work against all defects that may occur within three months from the completion of the Contract and will be required to make good such defects at their own cost.

#### 2.7 Insurance

The Contractor shall provide adequate public liability insurance.

#### 2.8 Performance and Inspection of Work

Inspection of the whole of the work at each of the stages scheduled may be made. Agree a programme that will facilitate such inspection, who and how inspections or reporting will be done, including notification when each part and stage of the work is ready for inspection.

# **3.0 PRODUCTS AND MATERIALS**

#### 3.1 WoodMaster Wood Coating

Dryden WoodMaster is a decorative low build wood preservative stain based on:

- High quality resins
- Weather resistant
- Insecticides and fungicides

Gives durable protection against blue stain, wood-rotting fungi and wood-boring insects. Decorates wood and enhances the natural beauty of the grain.

For exterior cladding, joinery, wood panelling, doors, trim and cabinets. Particularly recommended for use on hard woods. Dryden WoodMaster gives wood protection where required, e.g. damp rooms, roof constructions and other load-bearing structures.

#### **3.2 Properties**

Water - repellent, does not crack, peel or blister, easy to apply (Priming and undercoating not necessary, just brush on). WoodMaster is ready -for-use and must not be diluted. Retreatment is simple.

FLAMMABLE LIQUID CLASS 3, UN NO. 1263, Packing Group 111, Hazchem 3 (Y)

#### **3.3 Colour Toning**

WoodMaster is available in a range of colours, to match the Dryden WoodOil colour range which helps maintain and complement timber character and colour. All colours are intermixable if a non standard colour is required.

It is recommended that if a colour is chosen that for maximum retention it is used in all applications of WoodMaster to the timber.

Dryden WoodMaster colours are approximate only, as the actual raw timber colour, seasoning and application rate will determine the final colour achieved.

A more natural appearance is obtained by colour being contained by the surface fibre; because of this colour retention is better on rough timber than on smooth timbers.

Part-used cans have a limited life and can alter appearance.

# 4.0 EXECUTION

To conform to the best trade practice which shall be deemed to include those methods, practices and techniques contained in AS/NZS 2311, MPNZA Specification manual and the OSH publication "Guidelines for the provision of facilities and general safety in the construction industry". Comply with Dryden WoodMaster requirements and any additional requirements in this specification.

#### 4.1 Preparation

Refer to both Dryden WoodMaster Specification and Data Sheets for preparation.

#### 4.2 Use

Use paint strippers, cleaning agents, mould inhibitors, degreasers, knotting and fillers to the Dryden WoodMaster requirements, using those products that are specified on our Data Sheets.

#### **4.3 Restore Weathered Wood Surfaces**

Restore timber prior to coating WoodMaster with Dryden Surface Cleaner or Dryden Liquid Timber clean to Dryden requirements, where the timber is weathered, shows signs of environmental grime, mould, watermarks or discolouration. Contact Dryden if unsure.

#### **4.4 Pre-Stained Surfaces**

Ensure surface coating, stained, polyurethane surfaces previously coated with non Dryden WoodMaster are stripped back to bare timber prior to application of WoodMaster, unless otherwise directed. Contact Dryden if unsure.

#### 4.5 Compatibility

Check that materials are as required by Dryden WoodMaster, for the particular surface and conditions of exposure, and that they are compatible with each other.

#### **4.6 Treated Surfaces**

Check that surfaces that have been treated with preservatives or fire retardants are compatible with the coating material. If unsure, obtain instructions before proceeding.

#### 4.7 Hardware

Do not paint hinges or hardware that cannot be removed. Carefully remove hardware, fixtures and fittings before commencing work. Set aside where they cannot be damaged or misplaced and replace on completion. Refer to SELECTIONS for hardware, fixtures and fittings for removal.

#### **4.8 Protection**

Use drop sheets, coverings and masking necessary to protect adjoining fixtures, fittings and spaces from drops, spots, spray and damage.

#### 4.9 Colour

Refer SELECTIONS section. WoodMaster, colours, print on paper, internet web site, colour chips and liquid and supplied samples are a representative guide only as the timber type, the actual raw timber colour, exposure and seasoning of timbers and the quantity of oil applied, will also determine the final colour achieved.

Part-used cans have a limited life and can alter appearance.

# **5.0 APPLICATION – PREPARATORY WORK**

### **5.1 Sequence of Operations**

Painting work to generally follow the sequence below:

- Contact Dryden to instigate a programme to facilitate an inspection or reporting of work complete (new builds).
- Have timbers on site away and protected from contaminates and environmental grime.
- Complete all surface preparation before commencing coating.
- Ensure pails are matched/boxed for whole vicinity/section, check colourtone provided against spec/control samples.
- 1st Coat, allow applicable coverage rates safe fillet stacked storage until wet look has subsided.
- Coat board's full length linearly and complete individual walls at one time, use good painting practices.
- Coat all cut ends prior to or when fixing.
- Apply primers, sealers and clear coatings in the sequences specified by Dryden.
- 2nd coat, allow applicable coverage rates and full drying time between coats as season and timber dictate.
- Clean up over-spray or accidental spillage on unwanted surfaces such as windows.
- Protect new work from damage from contaminate type site work not complete.

#### 5.2 Delivery

Protect materials during transit. Check materials on delivery for condition. Reject and replace damaged materials.

#### **5.3 Moisture Content**

WoodMaster should only be applied to dry timbers (ideal conditions: weather dry, maximum 17% moisture content). LOSP treated timber must not be coated until the chemicals in the treatment process have evaporated from the timber, refer LOSP timber manufacturer's Data Sheet.

#### **5.4 Preparing Dressed Timber**

Ensure dressed timber is smooth, free from raised or woolly grain, planning burrs or other machining defects. In some instances the option to slightly round or ease sharp edges to ensure they can be properly coated, to a minimum 3 mm could be considered and flat sawn, dressed weatherboards can be sanded with a suitable grit sandpaper to slightly roughen the surface and remove mill glaze. Remove any dust or dirt by thorough brushing of surfaces. Fill large cracks with suitable fillers but ignore small.

NOTE: use only oil based paints on linseed-oil based window putties.

Do not use steel wool wire brushes as iron fragments cause staining.

#### 5.5 Preparing Rough Sawn Timber

Thoroughly brush along the direction of the grain to remove dust and debris. After brushing, turn timber over and bang several times to ensure all loose fibres fall off. Fill large cracks with suitable fillers but ignore small. NOTE: use only oil based paints on linseed-oil based window putties. Do not use steel wool wire brushes as iron fragments cause staining.

#### 5.6 Fixings

Take timber fixings below the painted or clear finished surface. Leave corrosion resistant timber fixings flush with clear finished surfaces.

#### **5.7 Sharp Edges**

Ensure sharp edges on timber are sanded to a rounded profile to ensure adequate product cover. Apply a stripe coat of each specified coating onto steelwork welds and sharp edges. Sand, grind or file sharp edges on other substrates to a rounded profile where practicable.

#### **5.8 Remedial Work**

If any substrate or surface cannot be brought up to a standard that will allow painting or clear finishing of the required standard then do not proceed until remedial work is carried out.

#### 5.9 Gap Filling

Fill large cracks with suitable fillers but ignore small. NOTE: use only oil based paints on linseed-oil based window putties. Do not use steel wool wire brushes as iron fragments cause staining.

# **6.0 APPLICATION – TIMBER**

#### **6.1 Initial Coats On Site**

Shake or stir the can thoroughly before and during use. Establish correctness of colour by test applications to off - cuts. We recommend that one coat of Dryden WoodMaster is applied to each side of cladding/timbers prior to attachment.

End-grain sealing using many coats of WoodMaster including cut ends to exclude moisture is especially important. Then apply second coat after fixing and nailing.

*Interiors:* one coat or more if required, Depth of colour can be altered by shortening or lengthening the time the stain is allowed to remain on the surface before wiping. For example, if a lightly stained look is desired, wipe the stain within two to three minutes of applying. If a deeper shade is desired, leave the stain on the surface for ten to fifteen minutes. Experiment first to determine the effect you desire. To achieve darker richer tones you may apply more than one coat.

Exteriors: minimum two full coats required.

Allow to dry 12 hours between coats: 24 hours needed for thorough drying. Then maintain to manufacturer's recommendations. Part-used cans have a limited life.

#### 6.2 Initial Coats, Factory Pre-Applied

Dryden WoodMaster first coat can be applied through a Pre-coat spray application; this System offers factory applied WoodMaster coating within a controlled environment delivering a seal to timber profiles.

Timbers must be protected from environmental conditions while not fixed.

End-grain sealing using many coats of WoodMaster including cut ends to exclude moisture is especially important.

*Interiors:* one coat or more if required, Depth of colour can be altered by shortening or lengthening the time the stain is allowed to remain on the surface before wiping. For example, if a lightly stained look is desired, wipe the stain within two to three minutes of applying. If a deeper shade is desired, leave the stain on the surface for ten to fifteen minutes. Experiment first to determine the effect you desire. To achieve darker richer tones you may apply more than one coat.

Exteriors: minimum two full coats required.

Allow to dry 12 hours between coats: 24 hours needed for thorough drying. Then apply second coat after fixing and nailing. Then maintain to manufacturer's recommendations. Part-used cans have a limited life.

#### 6.3 Coverage

WoodMaster coverage rates may vary due to porosity, moisture and timber type.

#### Approximate Coverage:

Hardwoods and woods with low permeability: 12-18 m²/litre per coat

Soft and permeable woods: Smooth / planned timber: 10-15 m²/litre per coat Rough sawn timber 5-6 m²/litre per coat

# 7.0 COMPLETION AND CLEAN UP

### 7.1 Uniform Colour Application

Leave the whole of this work uniform in colour, at the correct m<sup>2</sup> rate, free from painting defects, clean and unmarked and to the standard required by following procedures.

#### 7.2 Clean Up

Clean up splashes on metal or concrete immediately. Brushes etc. may be cleaned with Mineral turps. Part-used cans have a limited life.

#### 7.3 Remove

Remove drop sheets, coverings and masking to leave surrounding surfaces and areas clean, tidy and undamaged. Remove debris, unused materials and elements from the site. Dispose of all materials safely. Do not dispose of any material down stormwater systems. Contact your local council for correct disposal methods.

#### 7.4 Protect

Protect new work from damage. Take all relevant precautions to protect timbers from site work, dust, dirt, aggregate concrete wash, concrete cutting, metal grinding, water blasting, etc.

# 8.0 Dryden WoodMaster MAINTENANCE

#### 8.1 Re-application

Re-application of Dryden WoodMaster is required to areas where the surface exhibits signs of colour tone is fade principally UV exposed faces (in a less sound condition). This coat may be extended given better quality environmental conditions including shading, e.g. soffits.

We recommend washing of the surface to remove surface contaminants (dust, etc) with a mild detergent and clean water. This should also be done prior to any re-coats of WoodMaster if in good maintenance. If for any reason maintenance has not been kept up and the coating is in poor condition, it should be removed completely and the surface must be thoroughly sanded and then treated as "New timber".

# 9.0 SELECTIONS

#### Dryden WoodMaster Timber Coating.

Pre-Coats: Refer 6.1 or 6.2 Initial Coats

Please note:

#### 9.1 Location

Timber type:

Brand/Product: Dryden WoodMaster

Colour:

Coats: Two, Refer Application 6.1 or 6.2

### Schedule of paint systems

Area/substrate:

Colour and Code: Dryden WoodMaster

**Special Instructions:** 

Prep: See 5.4, 5.5

1st coat:

2nd coat:

#### **INFORMATION:**

If clarification or further information is needed the user should contact this company. The responsibility for products sold is subject to our standard terms and conditions. For more information on Dryden WoodMaster please refer to the Dryden WoodMaster SDS.

### For urgent emergency information only:

National Poisons Centre 0800 704 766

#### For additional information contact:

Dryden Distribution Ltd Free Phone: 0800 379 336 Phone: (09) 448 1335 Fax: (09) 448 1339 PO Box 300 661 – Albany Mega Centre – Auckland 0752 or visit www.dryden.co.nz

Revised Primary Dryden WoodMaster Coatings Specification Sheet: March 2015

#### 122011

Dryden WoodMaster Page 9 of 9